CPS Energy Addressing Requirements for Meter Installation

CPS Energy crews make every effort to assure your meter installation is completed accurately and ready for you when you need it.

Residential Meter Pole – Full address should be stenciled in black paint on meter can or disconnect panel

Commercial Structure with or without a Permanent Address and Meter Loop on Structure – Full address should be stenciled in blacr(.)-(la)-1it (o).-(nml)-(le)-2te)-2tcn(o)2trsconte (la)-1te